

DAYTONA

Technical Specifications

Composition: 55% POLYESTER, 35% ACRYLIC, 10% POLYAMIDE

Width: 140 cm. UNE 400335

Weight m2: 450 gr/m2

Tensile strenght: > 20 N (BS 4303) - > 3 daN (DIN 53859-5)

Tear strenght: > 350N (ISO 13934-1)

Tear displacement: Warp: < 4 mm - Weft: < 6 mm PR EN ISO 13936-2 (mm)

Abrasion resistance: > 200.000 cycles UNE EN ISO 12947

Pilling resitance: > 4 no pilling (ISO DIS 12945-2)

Dye resistance to rubbing: 4 Good (ISO 105-X12)

Dye resistance to light: 6 Good (ISO 105-B02)



DAYTONA 102



DAYTONA 108



DAYTONA 109



DAYTONA 110



DAYTONA 131



DAYTONA 137



DAYTONA 138



DAYTONA 139



DAYTONA 142



DAYTONA 145



DAYTONA 146



DAYTONA 151



DAYTONA 152



DAYTONA 153



DAYTONA 155



DAYTONA 156



DAYTONA 157



DAYTONA 158



DAYTONA 163



DAYTONA 164



DAYTONA 165



DAYTONA 183



DAYTONA 184



DAYTONA 49



DAYTONA 60



DAYTONA 72



DAYTONA 76



DAYTONA 77



DAYTONA 78



DAYTONA 80



DAYTONA 81



DAYTONA 86



DAYTONA 91



DAYTONA 98

Water cleaning in three simple steps



1. Remove any excess residue on the upholstery.
2. Apply water over the stain, either directly or using a damp cloth. Wait a few seconds.
3. Press down over the stain with the damp cloth and rub gently over the fabric using circular movements. If the stain does not come off completely, repeat the process as required.

Now, you can clean stains **with just water**

Aquaclean Technology® enables you to get rid of small stains such as wine, coffee, food and even most marker pens without having to wash with soap or detergent.

Maintenance and cleaning

· LIQUIDS OR OILS

Absorb the excess liquid or oil with a cloth or paper towel, then rub gently with circular movements.

· GREASE, PEN INK

Apply water over the stain, either directly or using a damp cloth, leave on the fabric for a few seconds, then rub the stain gently with circular movements. Repeat the process as many times as necessary. Always leave the fabric to dry.

· DUST

Remove the dust with a vacuum cleaner.



Washing

WASHING INSTRUCTIONS

For normal care, you don't need to remove and wash the sofa fabric. But for large or tough stains, before washing review the following instructions:

- Machine wash, delicate cycle (maximum 30°C).
- Use neutral detergents.
- Do not spin dry.
- No bleach.
- Do not dry in tumbler.
- Do not dry in sunlight.
- Do not squeeze or wring.
- Iron inside out.
- Use soft brush.
- Can be dry cleaned.